

#### Maintenance Check List

Installation Completion Date: 2-4-2014

Address: 5644 Corsica Loop

The following items have been provided and explained to the irrigation system owner or system owner's representative.

- The manufacturer's manual for the controller.
- A seasonal watering schedule.
- A list of components that require maintenance and the recommended frequency of maintenance is attached
- A permanent sticker has been attached to the controller indicating the warranty period for the irrigation system and contact information.
- The corrected or re-drawn design plans indicating the actual installation and components of the system.
- Location and operation of the isolation valve.

Irrigation system owner/representative Date

This irrigation system has been installed in accordance with all applicable state and local laws, ordinances, rules, regulations or orders. I have tested the system and determined that it has been installed according to the irrigation plan and is properly adjusted for the most efficient application of water at this time.



Irrigator/Date

Irrigation Technician/ Date

# Best of Texas

POBOX 776 HUTTO, TX 78634 (512)228-4833 (512)852-9633 fax

Zone#	Description	Head Type	Run Time(Minutes)
<u>l</u>	bed	Spray-bubb	let 10-12
2-4	turf	spraus	25
5-6	turf	no tors	45
		· · · · · · · · · · · · · · · · · · ·	
tion and the second second days and the second			Approximately the second secon
aud dismulations is also as Salva interval (see Salva interval of		and the second s	
ngalamankan nga distangan karangan sangariph anka Abarah salak distance sangalah s			
	· paulit	4	

Average	State of the latter of
Cycles	Section Assessed to be
3	1
3	Sales of the sales
4	A-damping of our or
4	STATE OF STREET
7	Age & Subsection of
Ģ	464.48
l L	THE PERSON NAMED IN
11	
9	1
6	200
4	Section of the last of the las
3	200
	Cycles 3 3 4 4 7 9 11 11 9 6 4

#### **MAINTENANCE ITEMS**

Backflow device – Test Annually (Call Louis Sinclair 563-8762)
Y-strainer – Check annually for debris
Heads – Run system monthly to check for leaks or broken nozzles
Valve covers – Trim grass around cover to expose
Controller – Check seasonally for correct run times
Winter – Run system briefly every 2 weeks if system remains in off position

Irrigation									
Quantity	Symbol	Description	Part Number	Pressure	Flow	Radius			
Sprinklers									
1	•	Rain Bird 10F - 1804	10F	30 psi	1.58 gpm	10 ft			
30	0	Rain Bird 10H - 1804	10H	30 psi	0.79 gpm	10 ft			
17	0	Rain Bird 10Q	10Q	30 psi	0.39 gpm				
2	0	Rain Bird 1300A-F	1300AF	30 psi	1.7 gpm	0 ft			
2 2 4 6	•	Rain Bird 5000-MPR-30-H - 5004-PL-PC	MPR-30-H	45 psi		30 ft			
4	•	Rain Bird 5000-MPR-30-Q - 5004-PL-PC	MPR-30-Q	45 psi	1.4 gpm	30 ft			
6	0	Rain Bird 8H - 1804	8H	30 psi	0.52 gpm				
8	0	Rain Bird 8Q - 1804	8Q	30 psi	0.26 gpm	8 ft			
Meters/Pu	ımps								
1	[60]								
Backflow	Devices								
1	<u>©</u>	Febco 715 - 1"	715 - 1"						
Control V	alves								
7	Rain Bird 100-DVF		100-DVF						
Y-Straine	rs / Filter	S							
1	CITA CITA	Febco 650A-1"	4305						
Irrigation	Accesso	ries							
1	M	Nelson 9501-100IN	9501-100IN						
1	A	Rain Bird ESP-4Me	ESP4ME						
1		Rain Bird RSD-BEx	RSD-BEx						
Lateral Li	ne Pipe								
602 ft	ft ——— Class 200 1" 0								
Mainline I	Pipe	**************************************							
189 ft	189 ft =====   Class 200 1"   0								

Water Source #1				
Meter Size	5/8 inch meter			
Static Pressure	65 psi			
Elevation Change	0 ft			
Service Line Information				
Pipe Category	Class 200 PVC			
Pipe Size	Class 200 1"			
Length	5 ft			
Velocity	5 fps			
Recommendations				
Maximum Recommended Flow	13 gpm			
Available Working Pressure	58.39 psi			

### 5644 CORSICA LOOP Design pressure all zones 65psi.





## JASON STUBBLEFIELD 2/4/2016



