

4050 FM 1660 Hutto, Texas 78634 2983 512-759-1286 Fax 512-759-

PWS I.D: 2460022	IN LOWI INLVEIVIN	JIN ASSEIVIDLY I	EST AND MAIN	TENANCE REPOR	≺1			
	_202 Makinaw St. Hutto, T.	X 78634						
	Taylor Morrison							
	/ICE 202 Makinaw St. ⊢							
INSPECTION DATE	_6/14/2024_12:20PM							
	tion assembly detailed brating within acceptable		d and maintained a	s required by TCEQ r	regulation	ns and		
		TYPE OF A	ASSEMBLY					
() Reduc	ed Pressure ZONE	() Reduced Press	() Reduced Pressure Principle-Detector					
(X) Double Check Valve			() Double Chec	k-Detector				
() Pressure Vacuum Breaker			() Spill-Resista	nt Pressure Vacuum	Breaker			
Manufacture	er: Apollo							
Model # DC	4A	Serial # 53617	′C					
Location of	device Right front yard	5 feet from meter _						
Is the assembly insta	lled in accordance with i	manufacturer recom	mendations and/or l	ocal codes? Yes				
	Reduced Pressure Principle Assembly				Pressure Vacuum Breaker			
	Reduced	Pressure Principle A	ssembly	Pressure	e Vacuun	n Breaker		
	Reduced Double Check Valve	<u> </u>	ssembly Relief Valve	Pressure Air Inlet	e Vacuun	n Breaker Check Va	llve	
		<u> </u>	· I	Air Inlet			ılve psid	
Initial Test	Double Check Valve	e Assembly	· I	Air Inlet Opened at p	osid H	Check Va		
Initial Test	Double Check Valve	2nd Check Held at 1.6 psid	Relief Valve Opened at psid	Air Inlet Opened at p	osid H	Check Va	psid	
Initial Test Repairs and Materials Used	Double Check Valve 1st Check Held at 2.0 Psi Closed Tight X Leaked	2nd Check Held at 1.6 psid Closed Tight X Leaked	Relief Valve Opened at psid	Air Inlet Opened at p Did not Open	osid H	Check Va	psid	
Repairs and	Double Check Valve 1st Check Held at 2.0 Psi Closed Tight X Leaked	2nd Check Held at 1.6 psid Closed Tight X Leaked	Relief Valve Opened at psid	Air Inlet Opened at p Did not Open	osid H	Check Va	psid	
Repairs and Materials Used	Double Check Valve 1st Check Held at 2.0 Psi Closed Tight X Leaked Held at psid	2nd Check Held at 1.6 psid Closed Tight X Leaked	Relief Valve Opened at psid	Air Inlet Opened at p Did not Open	osid H	Check Va	psid	
Repairs and Materials Used Test After Repair	Double Check Valve 1st Check Held at 2.0 Psi Closed Tight X Leaked Held at psid	2nd Check Held at 1.6 psid Closed Tight X Leaked Held at psid Closed Tight I	Relief Valve Opened at psid	Air Inlet Opened at p Did not Open	osid H	Check Va	psid	
Repairs and Materials Used Test After Repair The above is certification.	Double Check Valve 1st Check Held at 2.0 Psi Closed Tight X Leaked Held at psid Closed Tight Closed Tight	2nd Check Held at 1.6 psid Closed Tight X Leaked Held at psid Closed Tight □	Relief Valve Opened at psid	Air Inlet Opened at p Did not Open	osid H	Check Va	psid	
Repairs and Materials Used Test After Repair The above is certification.	Double Check Valve 1st Check Held at 2.0 Psi Closed Tight X Leaked Held at psid Closed Tight Closed Tight Ake / Model Mid West	2nd Check Held at 1.6 psid Closed Tight X Leaked Held at psid Closed Tight □	Relief Valve Opened at psid	Air Inlet Opened at p Did not Open d Opened at p	osid H	Check Va	psid	

Firm Phone # 512-605-9790

- TEST RECORDS MUST BE KEPT FOR AT LEAST THREE YEARS ** USE ONLY MANUFACTURER'S REPLACEMENT PARTS